



## GEV – Testing Method

**Determination of Volatile Organic Compounds  
for Evaluation of Emissions Controlled Products for Flooring  
Installation, Adhesives, Construction Products,  
as well as Lacquers, Finishes and Oils  
for Parquet, for Mineral Floorings and for Resilient Floorings**

(Edition: 04.04.2019 – replaces: 18.04.2018)

## Table of contents

1.	Abstract .....	3
2.	Introduction.....	3
2.1	Scope .....	3
2.2	Abbreviations.....	3
2.3	Apparatus .....	4
3.	Procedure .....	5
3.1	Sample material .....	5
3.2	Preparation of the test specimens.....	5
3.2.1	Liquid products .....	5
3.2.1.1	Procedure for water based precoats / primers (including barrier / damp proof primers / liquid membranes DPM) .....	5
3.2.1.2	Procedure for other thin fluid products .....	5
3.2.2	Powdery products.....	6
3.2.2.1	Procedure for powdery products that are tested with 3 mm layer thickness .....	6
3.2.2.2	Procedure for powdery products that are tested with 12 mm layer thickness .....	6
3.2.2.3	Procedure for powdery products that are tested with smaller layer thickness and that are tested with 300 g/m <sup>2</sup> .....	7
3.2.3	Pasty products.....	7
3.2.3.1	Procedure for one-component products.....	7
3.2.3.2	Procedure for pasty two- or multi-component and powdery products .....	8
3.2.4	Ready-to-use products .....	8
3.2.4.1	Procedure for products packed as sheets or in tapes.....	8
3.2.4.2	Procedure for tiles and assembled products.....	8
3.2.5	Joint sealants .....	8
3.2.6	Lacquers, finishes, oils and supporting products for parquet, for mineral floorings and for resilient floorings .....	9
3.2.7	Joint insulations .....	9
3.2.8	Joint sealing tapes.....	10
3.3	Operation of the test chamber and conditioning chamber .....	10
3.3.1	Preparation of the test chamber.....	10
3.3.2	Operating parameters .....	10
3.3.3	Control measures and documentation .....	10
3.3.4	Pre-conditioning and transfer of the test specimen into a chamber.....	11
3.3.5	Periods in the chambers and time schedule of air sampling.....	11
3.4	Testing of carcinogenic substances cat. 1 .....	11
3.5	Testing of the emissions of aldehydes and ketones .....	11
3.5.1	Air sampling.....	11
3.5.2	Analysis .....	11
3.6	Testing for VOC, SVOC and VVOC emissions .....	12
3.6.1	Air sampling.....	12
3.6.2	Analysis .....	12
3.6.2.1	Desorption and injection.....	12
3.6.2.2	Gas chromatography .....	12
3.6.2.3	Identification .....	12
3.6.2.4	Quantification .....	13
3.6.2.5	Complex substance mixtures .....	13
3.6.2.6	Normalization and re-calculation.....	13
3.6.2.7	TVVOC, TVOC, TSVOC, R-Value, sum VOC without LCI (NIK) .....	14
3.6.2.8	Precision and accuracy .....	14
3.7	Documentation of results.....	14
3.7.1	Internal documentation in the testing laboratory .....	14
3.7.2	Report to the customer.....	15
3.7.3	Storage of data.....	15
3.8	Quality Control.....	15
4.	Revision of this method.....	15
5.	References .....	15
6.	Product index .....	16

## 1. Abstract

The emissions behaviour of flooring installation products, adhesives, construction products as well as lacquers, finishes and oils for parquet, for mineral floorings and for resilient floorings<sup>1</sup> – in the following called “products” – is determined after a well-defined storage period in a test chamber. Short-term (after 3 days) and long-term (after 28 days) emissions are evaluated. Testing is performed for a number of substances that are recognised or suspected carcinogens (C1A, C1B) and for sum parameters (TVOC, TSVOC etc.). Testing is performed in line with EN 16516, considering European directives on hazardous substances.

## 2. Introduction

Any testing to determine the emissions of products have to be performed by a testing laboratory with an accreditation according to ISO 17025 that covers this GEV testing method.

Documentation of the results is done by the manufacturer according factory-internal rules.

### 2.1 Scope

Determination of the emission of volatile organic compounds (VOC) from products:

- (1) Testing covers a number of substances as specified in 3.4 that are recognised or suspected carcinogens (C1A, C1B) according to the European directives on hazardous substances.
- (2) Testing covers polar and non-polar substances that vaporise and appear in gaseous form after a defined storage period.

The testing conditions reflect usual and average ventilation and climate in Central European buildings.

They allow a comparative rating of products with regard to their long-term emissions behaviour and the general exclusion of recognised and suspected carcinogens. The test results are reported as air concentrations under precisely defined conditions, as specified in EN 16516 as European Reference Room.

### 2.2 Abbreviations

1C	=	one-component
2C	=	two-component
VOC	=	volatile organic compound (covering the range <i>n</i> -hexane ( <i>n</i> -C <sub>6</sub> ) to <i>n</i> -hexadecane ( <i>n</i> -C <sub>16</sub> ))
TVOC	=	total volatile organic compounds
SVOC	=	semi-volatile organic compound (covering the range above <i>n</i> -hexadecane ( <i>n</i> -C <sub>16</sub> ) to <i>n</i> -docosane ( <i>n</i> -C <sub>22</sub> ))
TSVOC	=	total semi-volatile organic compounds
VVOC	=	very volatile organic compound (covering the range below <i>n</i> -hexane ( <i>n</i> -C <sub>6</sub> ))
TIC	=	total ion current chromatogram

---

<sup>1</sup> Synthetic resin coatings (e.g. PUR and Epoxy) are not included.

## 2.3 Apparatus

- Tools for sample application (see also 3.2)
- Glass plates:
  - the size depends on the chamber volume and the intended loading factor;
  - degrease and clean the plates prior to testing, using a suitable procedure that does not affect the blank value;
- Glass dishes with a flat bottom (e.g. Petri dishes) or glass plates with a rim:
  - the size depends on the chamber volume and the intended loading factor;
  - degrease and clean the dishes prior to testing, using a suitable procedure that does not affect the blank value;
- Product specific moulds made of inert material to prepare a test specimen each for, e.g.:
  - Screeds and screed materials
  - Levelling compounds
  - Joint fillers or sealants
  - Joint insulations
  - Joint sealing tapes

- Notched trowel TKB-B1

The trowel has triangular notches with the following dimensions:

Dimension		Tolerance	
a	Bridge width / groove clearance	2,6 mm	± 0,1 mm
b	Notch width / groove width	2,4 mm	± 0,1 mm
c	Notch depth / groove depth	2,0 mm	± 0,1 mm
$\gamma$	Notch angle	55 °	± 0,5 °

- Non-emitting tape or aluminium foil for sealing of edges
- Test chamber:
  - Volume of the test chamber: Minimum 100 litres
  - Material: Stainless steel or glass
  - Air clean-up unit and humidification unit
  - Flow-meter for adjustment and documentation of the air flow rate through test and storage chambers
- Sampling devices for test chamber air
- Adsorbents for air sampling according to 3.4, 3.5 and 3.6
- Conditioning chamber:
 

Separate, air-tight conditioning chamber operated at 23 °C, 50 % RH, and an area specific ventilation rate as for emissions testing. Conditioning chambers shall be made of stainless steel or glass.
- Capillary gas chromatographic device with thermal desorption unit, coupled to a mass spectrometer with a data processing unit
- Liquid chromatographic device with a UV absorption detector or a Diode Array detector

## 3. Procedure

### 3.1 Sample material

Samples delivered for emissions testing that have been produced maximum 8 weeks ago. Products received in a closed container (can or cartridge) for wet application shall be tested not later than 4 months after sampling. This applies as well to powdery products that are meant to be mixed with a liquid component or water that is free of VOC. It is the responsibility of the ordering body to supply such fresh material. The date of production shall be disclosed. The samples are usually dispatched in a commercially available package. The content is mixed uniformly by the test laboratory, and a retained sample is taken out.

### 3.2 Preparation of the test specimens

Ready-to-use products are tested in their state of delivery. One-component products are homogenised before preparing the test specimen. For two- or multi-component products each component first is homogenised and then mixed as prescribed by the manufacturer before preparing the test specimen.

The test specimens are prepared in different ways, depending on the nature of the respective product.

The preparation of the test specimens has to be done exactly according to the following specifications.

#### 3.2.1 Liquid products

This includes products that are applied and tested as a thin layer.

##### 3.2.1.1 Procedure for water based precoats / primers (including barrier / damp proof primers / liquid membranes DPM)

If the solids content is not reported by the manufacturer, determine it by drying a separate part of the sample at 105 °C until constant weight, as described in ISO 1625.

Use water which is free of VOC to adjust the sample to 10 % solids content on the basis of the reported (alternatively the measured) solids content of the original sample and homogenise. Pour as much of the (possibly diluted) sample into a pre-weighted glass dish (see 2.3) such that it is loaded with  $100 \pm 5 \text{ g/m}^2$ . If the solids content of the product is lower than 10 % then add more into the dish until a loading of  $10 \pm 1 \text{ g/m}^2$  solids is reached. Wet the bottom evenly by swinging the dish. Transfer the test specimen into the test chamber immediately after preparation. After testing is completed the test specimen is weighed back to ensure that the dried film weighs  $10 \pm 1 \text{ g/m}^2$ .

##### 3.2.1.2 Procedure for other thin fluid products

This includes:

- Water-free precoats / primers (including barrier / damp proof primers / liquid membranes DPM)
- Ready-to-use thin fluid fixatives and adhesives (e.g. anti-slip coatings for self-laying floor coverings, rolled fixatives, spray adhesives, screw locking adhesives, wood glues)
- Liquid sealants (e.g. liquid membranes, reactive surface sealants)
- Binder for synthetic resin screed
- Casting resins
- Dispersion based additives for mineral tile mortars and levelling compounds
- Dispersion based bonding courses (e.g. for bonded screeds)

Test an undiluted sample with an amount of  $100 \pm 5 \text{ g/m}^2$  as described in 3.2.1.1. There is no need to weigh the sample back after testing is completed.

### 3.2.2 Powdery products

Products in powder form that are mixed as specified by the manufacturer.

This includes:

- Cement and calcium sulfate based levelling compounds
- Cement based and other mineral tile mortars (thin bed and medium bed mortars)
- Cement based joint grouts and mortars for brickwork
- Cement and calcium sulfate based screed mortars, cement and calcium sulfate based screed binding materials, powdery and liquid screed admixtures
- Powdery adhesives (not tile adhesives, but e.g. parquet or linoleum adhesives)
- Cement based waterproofing slurries 1C and 2C / powdery composite waterproofing coating
- Filling and levelling primers
- Quick cement

#### 3.2.2.1 Procedure for powdery products that are tested with 3 mm layer thickness

This includes:

- Cement and calcium sulfate based levelling compounds
- Cement based and other mineral tile mortars (thin bed and medium bed mortars)
- Cement based joint grouts and mortars for brickwork
- Quick cements

Mix the sample uniformly according to the instructions given by the manufacturer using water that is free of VOC, or with a supplied liquid component. Let the mixture stand for about 5 minutes and mix thoroughly once again. Prepare products with a shorter processing time (e.g. quick cements) as specified by the manufacturer.

Apply an even layer onto a glass plate (see 2.3) in 3 mm thickness and smooth the surface with a straight trowel.

Fix the edges of the loaded surface using an emission free rim of sufficient height that is made of e.g. glass or stainless steel. Transfer the test specimen with the rim into the test chamber immediately after preparation.

#### 3.2.2.2 Procedure for powdery products that are tested with 12 mm layer thickness

This includes:

- Cement and calcium sulfate based screed mortars
- Cement and calcium sulfate based screed binding materials
- Powdery and liquid screed admixtures

Mix the sample uniformly according to the instructions given by the manufacturer using water that is free of VOC, or with a supplied liquid component. Let the mixture stand for about 5 minutes and mix thoroughly once again.

- Cement and calcium sulfate based screed mortars are mixed with water that is free of VOC as specified by the manufacturer.
- The same applies to cement and calcium sulfate based screed binding materials. But as primary step, mix 1000 g sand with 250 g binding material and water that is free of VOC as specified by the manufacturer. The sand shall be of grain size 0-8 mm and shall be supplied by the manufacturer. In case of control samples, sand of mesh type B8 as specified in DIN 1045-2 shall be used.

- Screed admixtures are prepared as like screed binding materials, but use a defined Portland cement CEM I 42,5 N to be supplied by the manufacturer instead of the binding material. Mix 250 g Portland cement with 1000 g sand (0-8 mm) and water that is free of VOC and the maximum dosage of the screed additive admixture as specified by the manufacturer.

Apply an even layer of the mixed sample onto a glass plate (see 2.3) in 12 mm thickness and smooth the surface with a straight trowel.

Mix the sample uniformly according to the instructions given by the manufacturer using water that is free of VOC, or with a supplied liquid component. Let the mixture stand for about 5 minutes and mix thoroughly once again.

### **3.2.2.3 Procedure for powdery products that are tested with smaller layer thickness and that are tested with 300 g/m<sup>2</sup>**

This includes powdery products (but no cement based or other mineral tile mortars such as thin bed and medium bed mortars):

- Parquet or linoleum adhesives
- Cement based waterproofing slurries 1C and 2C / powdery composite waterproofing coating
- Powdery filling and levelling primers
- Powdery bonding courses (e.g. for bonded screeds)

These products are mixed as specified in 3.2.3.2 and tested with an application amount of 300 g/m<sup>2</sup>. Preparation of the test specimen is specified in 3.2.3.1.

### **3.2.3 Pasty products**

This includes products that are pasty when applied:

- 1C and 2C pasty adhesives for floor coverings and parquet based on dispersions or reactive resins
- Assembly adhesives
- Pasty fixatives for floor coverings and other pasty adhesives
- Levelling compounds based on dispersions or reactive resins
- Ready-to-use adhesives for ceramic tiles based on dispersions or reactive resins
- Sealants under tiles based on dispersions or reactive resins (composite waterproofing coatings)
- Joint grouts based on dispersions or reactive resins

Prepare the test specimen as specified in 3.2.3.1 and 3.2.3.2.

#### **3.2.3.1 Procedure for one-component products**

Transfer the sample in excess onto a pre-weighed glass plate (see 2.3) and spread it with a notched trowel TKB-B1 (60° blade angle) in one stroke. This shall be carried out in such a way that the sample is uniformly structured across the whole area. Full coverage application in glass dishes with a flat bottom and a rim is performed if the above procedure cannot be applied to products with low viscosity. Weigh the plate back and record the weight of the specimen. The sample must weigh  $300 \pm 10$  g/m<sup>2</sup>. A higher application amount is possible if requested by the ordering body.

The preparation shall not take more than 3 minutes. Transfer the test specimen into the test chamber immediately after preparation.

### 3.2.3.2 Procedure for pasty two- or multi-component and powdery products

Mix the components as specified by manufacturer. Prepare the test specimen as described in 3.2.3.1.

### 3.2.4 Ready-to-use products

This includes products that do not require any chemical curing or physical drying:

- Underlays (e.g. footfall damping underlays)
- Self-adhesive underlays and tapes
- Installation panels, decoupling panels, damping panels and wall panels
- Sealing membranes, tapes, collars for small surfaces (e.g. for window, façade, wet areas)
- Sealing membranes for large surfaces (e.g. for walls and floor in wet areas), vapour retarder under the roof

#### 3.2.4.1 Procedure for products packed as sheets or in tapes

Take the sample from a position 2 m into the roll. In case of a wide roll, take a sample with an area of at least 1 m<sup>2</sup> from the centre of the roll. In case of a roll less than 1 m wide, take a sample of sufficient length over the whole width.

Roll the sample as far as possible against the direction of the production roll. Secure the sample (if possible) using staples, wrap it twice in aluminium foil and pack it in unprinted and airtight polyethylene or polypropylene foil. Each foil must contain only one sample. The elapsed time between taking and packing the sample must not exceed 1 hour.

The sample is unpacked in the testing laboratory immediately prior to testing. The back side is fixed tightly onto an inert plate. A product with a self-adhesive back side is glued directly onto the plate with its full surface. Remove the protective foil from products with a self-adhesive upper side. All open edges of products more than 1 mm thick shall be sealed with an inert material, e.g. a non-emitting tape or aluminium foil. Materials used for sealing of back and edges must be shown to be emission-free. Testing without such sealing is possible as well.

#### 3.2.4.2 Procedure for tiles and assembled products

Tiles and assembled products are preferably dispatched in a normal commercial package unit, additionally wrapped twice in aluminium foil and packed in unprinted and airtight polyethylene or polypropylene foil. The sample is unpacked in the testing laboratory immediately prior to testing. The material to be tested is taken out of the middle of the package. The test specimen is either cut or put together to the proper size for testing. It is fixed tightly onto the bottom of the test chamber. All open edges must be sealed with inert material, e.g. a non-emitting tape or aluminium foil. Testing without such sealing is possible as well.

### 3.2.5 Joint sealants

This includes pasty products based on dispersion or reactive resins that are used e.g. to seal joints between adjacent components. Apply the sample without bubbles into a mould made of inert material (e.g. stainless steel, glass, Teflon) with 3 mm depth and 10 mm width and smooth the surface with a straight trowel (e.g. made of Teflon). The length of the mould shall correspond to the required loading factor and the size of the test chamber.



### 3.2.6 Lacquers, finishes, oils and supporting products for parquet, for mineral floorings and for resilient floorings

This includes:

- Parquet oils
- Water based parquet coatings
- Water based parquet primers
- Water based joint fillers for parquet
- Water based lacquers<sup>2</sup> and finishes<sup>3</sup> and oils for mineral floorings, e.g. levelling compounds, screeds, natural stone, stoneware
- Water based lacquers<sup>2</sup> for resilient floorings, e.g. vinyl floorings
- Water based UV coatings for parquet and resilient floorings
- UV curing lacquers (100% solids) for parquet and resilient floorings

Pour as much of the sample into a pre-weighted glass dish (see 2.3) that the following application amounts are transferred into the test chamber:

- For water based lacquers for parquet:  $150 \pm 2 \text{ g/m}^2$
- For water based lacquers for and finishes and oils for mineral floorings:  $100 \pm 2 \text{ g/m}^2$
- For water based lacquers for resilient floorings:  $50 \pm 2 \text{ g/m}^2$
- For oils:  $25 \pm 2 \text{ g/m}^2$
- For water based primers for parquet:  $100 \pm 2 \text{ g/m}^2$
- For water based joint fillers for parquet:  $100 \pm 2 \text{ g/m}^2$
- For water based UV lacquers:  $150 \pm 2 \text{ g/m}^2$
- For UV curing lacquers with 100% solids  $50 \pm 2 \text{ g/m}^2$

Wet the bottom evenly by swinging the dish. Distribute evenly with a brush if necessary. Transfer the test specimen into the conditioning chamber immediately after preparation.

Alternatively, the same quantity can be applied on a glass plate.

Even though testing of parquet lacquers, primers and oils on wooden substrate is not recommended<sup>4</sup>, results from such testing can be taken into account for an evaluation of emissions.

Testing with several layers on wood, with in total higher application, is not recommended but is possible. In that case drying periods between the layers shall be applied as specified by the manufacturer.

After wet application, water-based UV lacquers are dried physically according to the manufacturer's instructions. UV-curing lacquers with 100 % solids are ventilated for 30 minutes after application. UV curing is then carried out according to the manufacturer's specifications using a suitable device.

### 3.2.7 Joint insulations

This includes assembling and sealing foams expanding during application. They are used to seal joints around window frames.

---

<sup>2</sup> Synthetic resin coatings (e.g. PUR and Epoxy coatings) are not included.

<sup>3</sup> No maintenance products.

<sup>4</sup> Testing on wood is not recommended, because the emissions from the wood itself, and different porosity of different wooden plates, can deteriorate the test result.

A moistened mould made of HDPE or Teflon is filled with foam in a circa 30 mm thick layer. The form has a width of 100 mm and a height of 16 – 19 mm. After 2 hours (120 ± 10 minutes) the test specimen is cut flatly to 16 – 19 mm height and it is placed into a 15 mm wide and 100 mm deep sample holder (U profile with covered edges, trough shaped) made of inert material (e.g. stainless steel, glass, Teflon) with this slight oversize. The length of the form and of the sample holder shall correspond to the required loading factor and the size of the test chamber.

### 3.2.8 Joint sealing tapes

This includes pre-compressed joint sealing tapes made of foam as specified in DIN 18542. They are used to seal joints around window frames.

A sample of the tape is placed into a 15 mm wide and 100 mm deep sample holder (U profile with covered edges, trough shaped) made of inert material (e.g. stainless steel, glass, Teflon). The length of the sample holder shall correspond to the required loading factor and the size of the test chamber.

## 3.3 Operation of the test chamber and conditioning chamber

Parameters not specified differently in this GEV testing method shall follow EN 16516.

### 3.3.1 Preparation of the test chamber

Prior to emission testing a blank check of the test chamber has to be carried out. The blank values as specified in EN 16516 with reference to EN ISO 16000-9 must not be exceeded. Clean the test chamber if necessary before placing the test specimen into the chamber. After cleaning the blank value has to be checked.

### 3.3.2 Operating parameters

The following parameters shall be adjusted in the test chamber:

Parameter	Value	Tolerance
Temperature (chamber and supply air)	23 °C	± 1 °C
relative humidity (supply air)	50 %	± 5 %
area specific air flow rate (usually defined by the parameters air exchange rate and loading factor)	1,25 m <sup>3</sup> / (m <sup>2</sup> x h) or 71 m <sup>3</sup> / (m <sup>2</sup> x h) (joint sealants, sealings and tapes)	results from tolerance of air change and loading
air exchange rate in test chamber	0,5 h <sup>-1</sup>	0,25 – 1,5 h <sup>-1</sup> *, ± 5 % during test
loading factor for large surfaces	0,4 m <sup>2</sup> /m <sup>3</sup>	0,2 – 0,8 m <sup>2</sup> /m <sup>3</sup> *
loading factor for small surfaces (joint sealants, sealings, sealing tapes, sealing membranes e.g. for windows)	0,007 m <sup>2</sup> /m <sup>3</sup>	0,0035 – 0,014 m <sup>2</sup> /m <sup>3</sup> *
air flow (measured 10 mm above centre of sample)	0,2 m/s	0,1 – 0,3 m/s

\* The parameters shall comply with the specified values in the second column. In the case of deviations, the parameters shall be within the specified tolerance ranges, and the results shall be calculated back to the specified values as outlined in EN 16516.

### 3.3.3 Control measures and documentation

A continuous measurement and documentation of the parameters temperature, humidity and air flow is recommended to be performed by suitable sensors.

The efficiency of air mixing with a test specimen or an inert support of test specimen loaded in the test chamber (for methodology, see EN ISO 16000-9) shall be evaluated within the quality assurance program. The result has to be documented.

### 3.3.4 Pre-conditioning and transfer of the test specimen into a chamber

Only products specified in 3.2.6 shall be stored in a separate pre-conditioning chamber during 3 days ( $72 \pm 1$  hours). Testing is possible without such pre-conditioning as well if requested by the ordering body.

Test specimens must be transferred into the chamber immediately after preparation. Any contamination of test specimens with emissions from other sources must be avoided. The loading of the test chamber shall be adjusted according to 3.3.2.

### 3.3.5 Periods in the chambers and time schedule of air sampling

Air sampling for first VOC test and for aldehydes test is performed 3 days ( $72 \pm 1$  hours) after transfer of the test specimen into the chamber. Start time and end time of air sampling shall be within the specified interval of  $\pm 1$  hour.

Then the test specimen has to remain in the test chamber until finalizing all later air sampling.

Air sampling for long-term emissions test is performed 28 days ( $672 \pm 4$  hours), after transfer of test specimen into test chamber. Start time and end time of air sampling shall be within the specified interval of  $\pm 4$  hours.

Alternatively compliance can be shown if all criteria (28 days limit values) are respected already at an earlier point of time, but not earlier than after 10 days, under the condition that the emissions did not increase, compared with the emissions after 3 days.

## 3.4 Testing of carcinogenic substances cat. 1

Emission testing is carried out 3 days and 28 days after start of test in the test chamber for volatile carcinogenic compounds cat. 1A and 1B<sup>5</sup>.

An analytical reporting limit of  $1 \mu\text{g}/\text{m}^3$  for each carcinogenic substance shall be targeted, as far as technically feasible. Test methods are specified below.

Testing method as specified in 3.5 and 3.6 shall be applied. Carcinogenic substances of cat. 1A and 1B are monitored within the frame of the above specified emissions tests without additional sampling or analysis.

The emissions of formaldehyde and acetaldehyde are tested and evaluated separately after 3 days.

## 3.5 Testing of the emissions of aldehydes and ketones

Reference: DIN ISO 16000-3

### 3.5.1 Air sampling

Air sampling shall be performed after 3 days. An additional air sampling shall be performed after 28 days for evaluation of the R value for assignment of the EC 1<sup>PLUS</sup> level. Air sampling is performed onto silica gel or filters which both are impregnated with dinitrophenylhydrazine (DNPH), or into an aqueous solution of DNPH. Exposed DNPH filters must be analysed within two days after sampling to avoid loss of formaldehyde.

### 3.5.2 Analysis

Desorption with acetonitrile, separation by HPLC, identification and quantification by UV absorption detector or by diode-array detector with one or two specific wavelengths.

To avoid wrong results the analyst should pay attention to a complete chromatographic separation.

---

<sup>5</sup> A list of classified carcinogenic compounds (cat. 1A and 1B) can be seen here (in German language): <http://www.dguv.de/ifa%3B/fachinfos/kmr-liste/index.jsp>. A supplemental support for identification of relevant VOCs is the most recent list used by Deutsches Institut für Bautechnik (DIBt) as can be found in the evaluation file ADAM.

If a signal is present at the specific retention time in the chromatogram, it will be checked, whether the limit value for the given substance (see "GEV-Classification Criteria" par. 3.2.1) is exceeded. Further it shall be checked whether the spectrum of the signal peak is in accordance with the spectrum of the standard.

The analysis shall identify and quantify the following substances after 28 days for calculation of the R value: Formaldehyde, acetaldehyde, acetone.

### 3.6 Testing for VOC, SVOC and VVOC emissions

Air sampling and analysis shall be carried out in such a way that each single substance can be identified and quantified in the chamber from 1 µg/m<sup>3</sup> on, as far as technically feasible.

#### 3.6.1 Air sampling

The adsorption tubes are conditioned prior to sampling in a flow of helium as specified in EN ISO 16000-6. Take air samples on Tenax TA 60/80 with max. 120 ml/min, e.g. during 60 minutes, with a volume of max. 5 litres. Duplicate air sampling shall be performed. To avoid any loss of VOCs due to overloading, either two tubes (main and control tube) shall be connected in series, or two parallel sampling tubes shall be used with different air sampling volumes, e.g. 2 and 5 litres.

Volatile compounds such as acetic acid are poorly adsorbed by Tenax TA (low capacity). For these compounds the result from the adsorption tube with the lower air sampling volume is decisive.

The use of active charcoal as adsorbent is not accepted, because charcoal has a very poor recovery rate in the case of polar compounds (e.g. alcohols, glycol ethers etc.).

#### 3.6.2 Analysis

##### 3.6.2.1 Desorption and injection

The operating parameters depend on the analytical devices in use and shall be determined and adjusted by the testing laboratory. The following parameters are examples referring to the system Perkin-Elmer ATD-400.

Desorption of the tubes after air sampling by heating to e.g. 300 °C in a flow of helium, as specified in EN ISO 16000-6. It is recommended to carry out double desorption for a reliable determination even of less volatile compounds. Concentration step: Cryofocussing in a cold trap at -30 °C. Injection by rapid heating of the cold trap, e.g. up to 300 °C in one minute.

##### 3.6.2.2 Gas chromatography

Capillary gas chromatography, with 5 % phenyl / 95 % methylpolysiloxane, with helium as carrier gas, e.g. with a column of 30 m in length, inner diameter (ID): 0.25 mm, film thickness (d): 0.25 µm.

The GC analysis has to be carried out in a way that allows a reliable detection of substances including *n*-docosane (*n*-C<sub>22</sub>).

##### 3.6.2.3 Identification

By comparing spectra using the fragment ions or in the SIM mode using a scan range from 33-425 amu. Identification of all single components, but only if they result in more than 1 µg/m<sup>3</sup> concentration, when calculated from the TIC in toluene equivalents.

The identification is described in the following categories of identity:

- **ID Category 1: definitely identified**  
Prerequisite: The retention time and the mass spectrum of the signal peak matches with those of a standard.
- **ID Category 2: probably identified**  
Prerequisite: The mass spectrum of the signal peak matches with a reference spectrum of a standard library, the retention time is in the expected

time interval, and there is additional evidence for the identity (e.g. the presence of other isomers of the substance).

- **ID Category 3: possibly identified**  
Prerequisite: as category 2, but less stringent evidence.
- **ID Category 4: not identified**  
Prerequisite: no reliable evidence for the identity.

#### 3.6.2.4 Quantification

Calibration shall be performed as specified in EN 16516. Use of an internal standard is possible only if it is ensured that there is no overlapping between the internal standard peak and peaks of the air sample.

The definitely identified compounds (category 1):

- Substances for which there is a limit value are quantified using the relative response factors with the respective signal areas in the TIC, or - in the case of insufficient chromatographic separation - by using the response factors of characteristic fragment ions.
- All other substances are quantified using the respective signal areas in the TIC with toluene as reference substance for calibration (in toluene equivalents).

The single results of the main sampling and the control sampling tube are added if relevant. If the amount of single compounds in case of the control sampling tube is more than 25 % higher than the amount adsorbed on the main sampling tube then the result has to be marked with "greater than", because relevant loss of substances cannot be excluded.

Only compounds with more than 5 µg/m<sup>3</sup> concentration when calculated from the TIC in toluene equivalents, are considered for TVOC and TSVOC and R-value calculation. Quantified substances with less than 5 µg/m<sup>3</sup> shall be reported as "< 5 µg/m<sup>3</sup>" or "less than 5 µg/m<sup>3</sup>" because lower results show an increased measurement uncertainty not allowing more precise information. Precise data down to 1 µg/m<sup>3</sup> shall be given only for carcinogenic substances, as far as technically feasible. Results for acetic acid are not included in the calculation of TVOC and of the R value, as EN 16516 states that a reliable determination of acetic acid is not possible with this testing method.

#### 3.6.2.5 Complex substance mixtures

Complex mixtures of saturated hydrocarbons (aliphatic, cyclic, acyclic) that are not separated in a gas chromatogram and appear as a "cluster" of signals are evaluated as follows:

All specific VOCs of chemical nature different than the hydrocarbon mixture are evaluated each by each as far as feasible and quantified in line with 3.6.2.4. The whole area of each peak is calculated, from top of each peak down to baseline. The reporting limits of 3.6 (1<sup>st</sup> sentence) and 3.6.2.4 are applied.

All other specific VOCs are rated as part of the hydrocarbon mixture and quantified in toluene equivalents in line with 3.6.2.4. The whole area of each peak is calculated, from top of each peak down to baseline. The reporting limits of 3.6 (1<sup>st</sup> sentence) and 3.6.2.4 are applied.

The test result of the whole hydrocarbon mixture is calculated as the sum of all individual results, but without the VOCs that are chemically different from the hydrocarbon mixture.

Mixtures of aromatic hydrocarbons and of terpenes are treated in a similar manner.

#### 3.6.2.6 Normalization and re-calculation

Test results obtained with higher application amount than specified in this document are compared directly with emissions class limit values without correction, with the exception of the below mentioned products. The measured values are normalized to the standard application amount target application amount as given below, if necessary:

Result ( $\mu\text{g}/\text{m}^3$ ) = measured value ( $\mu\text{g}/\text{m}^3$ ) x standard application ( $\text{g}/\text{m}^2$ ) / applied amount ( $\text{g}/\text{m}^2$ ).

Standard application:

- 10 g /m<sup>2</sup> dry residue for water based primers
- 100 g/m<sup>3</sup> for ready-to-use liquid fixatives and adhesives.

Test results obtained with deviating loading factors or air change rates shall be calculated back to the standard values as follows:

Result ( $\mu\text{g}/\text{m}^3$ ) = Measured value ( $\mu\text{g}/\text{m}^3$ ) x Standard value of loading factor ( $\text{m}^2/\text{m}^3$ ) / Applied loading factor during test ( $\text{m}^2/\text{m}^3$ ).

Result ( $\mu\text{g}/\text{m}^3$ ) = Measured value ( $\mu\text{g}/\text{m}^3$ ) x Applied air change rate during test (per hour) / Standard value of air change rate (per hour).

### 3.6.2.7 TVVOC, TVOC, TSVOC, R-Value, sum VOC without LCI (NIK)

The results are summed up to the following parameters, depending on the retention time of the individual compounds on a - slightly polar column, see 3.6.2.2:

- TVOC:  
All compounds with more than 5  $\mu\text{g}/\text{m}^3$  in the gas chromatogram between and inclusive *n*-hexane and *n*-hexadecane (*n*-C<sub>6</sub> – *n*-C<sub>16</sub>), calculated in toluene equivalents (excluding emissions of acetic acid, see 3.6.2.4).
- TSVOC:  
All compounds with more than 5  $\mu\text{g}/\text{m}^3$  in the gas chromatogram after *n*-hexadecane (> *n*-C<sub>16</sub>) and before *n*-docosane (< *n*-C<sub>22</sub>), calculated toluene equivalents.
- TVVOC (only for products according to 3.2.6):  
All compounds with more than 5  $\mu\text{g}/\text{m}^3$  in the gas chromatogram before *n*-hexane (< *n*-C<sub>6</sub>), calculated in toluene equivalents.
- Others:  
For EC1<sup>PLUS</sup> the R-value (excluding emissions of acetic acid, see 3.6.2.4) and the sum of non-assessable VOCs are reported as specified by AgBB in the most recent version. This includes VVOC and SVOC with an LCI value as well that are determined by sampling on Tenax and on DNPH tubes

### 3.6.2.8 Precision and accuracy

A repeatability of test chamber air monitoring with the same test specimen within one testing laboratory of  $\pm 20\%$  or better should be aimed at. A larger variation has to be accepted in the trace range below 5  $\mu\text{g}/\text{m}^3$ .

The testing laboratory shall take special care to ensure traceability and accuracy of the calibration, and to know and consider recovery rates.

## 3.7 Documentation of results

### 3.7.1 Internal documentation in the testing laboratory

- Sample:  
Name, package, batch and date of production (if known), solids content (in case of primers), date of receipt in the laboratory.
- Test specimen:  
Glass plate (length, width), possibly mixing procedures before application, amount of sample (weight before and after preparation of the test specimen), spreading technique (used tool).

- Test chamber and conditioning chamber:  
Type and dimensions, temperature (mean and course), relative humidity (mean and course), air flow (in litres per hour, mean and course).
- Air sampling:  
Time (after preparation of test specimen), duration, adsorbent, sampling air flow, sampling volume.
- Storage:  
Storage time (in full hours) in the test chamber / conditioning chamber
- Results:  
All readings either as average or as single results of duplicate determination.

Documentation and storage of the raw data is done according to the Quality Assurance System (QA System) of the testing laboratory.

### **3.7.2 Report to the customer**

The summarising report to the customer includes at least a statement on the presence or absence of the C-substances according to 3.4 and documentation on the emissions according to 3.5 and 3.6 at all testing dates.

### **3.7.3 Storage of data**

The documentation of the results have to be stored by the testing laboratory for at least 10 years, back-up samples of the tested products for 2 months and the analytical raw data (TIC, mass spectra etc.) for at least 10 years. Apart from that the rules of the quality system concerning the storage of data shall be observed

## **3.8 Quality Control**

Control cards shall be used for the test chambers and for the analytical methods.

Blank control shall be carried out by air sampling prior to starting any test.

Control air sampling efficiency as specified in 3.6.1. Duplicate air sampling is essential to avoid random errors.

Control of all calculations and of each data transfer between two sheets or into EDP shall be carried out by a second person.

In regular intervals two test specimens are prepared from one single sample and the emissions are compared for checking reproducibility. Furthermore, recovery is determined by introducing a known amount of a compound into the test chamber which is inert and not emitted from the sample in the chamber.

To control the analysis method sampling tubes spiked with substance of known quantity are analysed regularly.

## **4. Revision of this method**

The Technical Council of the GEV is responsible for the contents of this test method. The GEV is responsible for all the documentation and for any revisions.

## **5. References**

EN 16516

EN ISO 16000 parts 3, 6, 9 and 11

ISO 17025

DIN 1045-2

## 6. Product index

<b>A</b>	
Additives for mineral levelling compounds (based on dispersions)	3.2.1.2
Additives for mineral tile adhesives (based on dispersions)	3.2.1.2
Adhesives (ready-to-use, thin fluid)	3.2.1.2
Adhesives for floor coverings (pasty, 1C or 2C, based on dispersions or reactive resins)	3..2.3
Adhesive tapes	3.2.4
Anti-slip coatings	3.2.1.2
Assembly adhesives (pasty)	3.2.3
<b>B</b>	
Barrier primers (based on water)	3.2.1.1
Barrier primers (water free)	3.2.1.2
Binder for synthetic resin screed	3.2.1.2
Bonding courses (powdery)	3.2.2.3
<b>C</b>	
Casting resins	3.2.1.2
Composite waterproofing coatings (powdery)	3.2.2.3
Composite waterproofing coatings (sealants under tiles based on dispersions or reactive resins)	3.2.3
<b>D</b>	
Damping panels	3.2.4
Decoupling panels	3.2.4
Damp proof barriers (water based)	3.2.1.1
Damp proof barriers (water-free)	3.2.1.2
<b>E</b>	
Expanding foams	3.2.7
<b>F</b>	
Filling binders	3.2.2.3
Finishes <sup>6</sup> for mineral floorings	3.2.6
Fixatives (ready-to-use, thin fluid)	3.2.1.2
Fixatives for floor coverings (pasty)	3.2.3
Floor covering adhesives (pasty, 1C or 2C, based on dispersions or reactive resins)	3.2.3
Footfall damping underlays	3.2.4
<b>G</b>	
Primers (water based)	3.2.1.1
Primers (water-free)	3.2.1.2
Primers for parquet oils	3.2.6
<b>I</b>	
Installation panels	3.2.4
<b>J</b>	
Joint fillers (water based) for parquet	3.2.6
Joint grouts (based on dispersions or reactive resins)	3.2.3
Joint grouts (cement based)	3.2.2.1
Joint insulations	3.2.7
Joint sealants (based on dispersions or reactive resins)	3.2.5
Joint sealing tapes made of foam	3.2.8
<b>L</b>	
Lacquers <sup>7</sup> or oils for mineral floorings	3.2.6
Lacquers or oils for parquet (water based)	3.2.6
Lacquers <sup>7</sup> for resilient floorings	3.2.6
Levelling compounds (based on cement or calcium sulfate)	3.2.2.1

<sup>6</sup> No maintenance products.

<sup>7</sup> Synthetic resin coatings (e.g. PUR and Epoxy coatings) are not included.



Levelling compounds (based on dispersions or reactive resins)	3.2.3
Levelling primers	3.2.2.3
Linoleum adhesives (powdery)	3.2.2.3
Liquid membranes	3.2.1.2
Liquid sealants	3.2.1.2
<b>M</b>	
Medium bed tile mortar mortars (cement based or mineral)	3.2.2.1
Mortars for brickwork (cement based)	3.2.2.1
<b>P</b>	
Parquet adhesives (pasty, 1C or 2C, based on dispersions or reactive resins)	3.2.3
Parquet adhesives (powdery)	3.2.2.3
Parquet lacquers (water based)	3.2.6
Parquet oils	3.2.6
Parquet primers (water based)	3.2.6
Primers (water-based)	3.2.1.1
Primers (water free)	3.2.1.2
<b>Q</b>	
Quick cements	3.2.2.1
<b>R</b>	
Reactive surface sealants	3.2.1.2
Rolled fixatives	3.2.1.2
<b>S</b>	
Screed admixtures (powdery or liquid)	3.2.2.2
Screed binding materials (based on cement or calcium sulfate)	3.2.2.2
Screed mortars (based on cement or calcium sulfate)	3.2.2.2
Screw locking adhesives	3.2.1.2
Sealing collars	3.2.4
Sealing foams	3.2.7
Sealing membranes for large surfaces	3.2.4
Sealing membranes for small surfaces	3.2.4
Spray adhesives	3.2.1.2
<b>T</b>	
Thin bed tile mortar mortars (cement based or mineral)	3.2.2.1
Tile adhesives (cement based or mineral)	3.2.2.1
Tile adhesives (ready-to-use, based on dispersions or reactive resins)	3.2.3
<b>U</b>	
Underlays	3.2.4
UV curing lacquers (100 % solids) for parquet	3.2.6
UV curing lacquers (100 % solids) for resilient floorings	3.2.6
Underlays (self-adhesive)	3.2.4
<b>V</b>	
Vapour retarder under the roof	3.2.4
<b>W</b>	
Wall panels	3.2.4
Water based UV parquet lacquers	3.2.6
Water based UV lacquers for resilient floorings	3.2.6
Waterproofing slurries (cement based, 1C or 2C)	3.2.2.3
Wood glues	3.2.1.2